





ODZRAČIVANJE

DOVOD ZATVOREN
NULTA POZICIJA




POGON

DOVOD OTVOREN
MANOMETAR POD TLAKOM



ISPUST

DOVOD OTVOREN
MANOMETAR IZVAN POGONA
TLAČNI MEDIJ SLOBODNO IZLAZI



MATERIJAL: MJED